



SLIDEMOOR MARINA INSTALLATION PACKAGE INSTALLATION INSTRUCTIONS

*Ensure the Installation Package was ordered for the diameter of the pilings that will hold the SlideMoor.
Ensure Marina Installation Package came with Spacers for clamp tightening.*

1. Determine the vertical track location and mark top of the track on piling.
 - a. Some have used a nail to help support the track during the assembly and tightening process.
2. Assemble two-part clamp onto the top holes of the track using (2ea) $\frac{3}{8}$ x 1 $\frac{1}{4}$ socket head bolts and Nylock nuts. Leave those bolts loose for now. Clamp can be installed with the compression bolt on either side of the piling as needed.
3. Install the $\frac{1}{2}$ " x 1" hex bolt in the bottom stop location on the track using a lock washer and hex nut, and tighten the bottom stop.
4. Slide the $\frac{1}{2}$ " x 5" compression hex bolt through two-part clamp using the $\frac{1}{2}$ " lock washer under the nut and leave loose.
5. Lift the track so top clamp goes over top of the piling and slides down to your top mark placed on the piling. Be sure to move the track so it is lined up between the piling and the boat.
6. Tighten clamp using (2ea) $\frac{3}{8}$ " bolts with the Nylock nuts through the tracks.
7. Snug the 5" compression bolt to hold the track in the proper position.
8. Once the top is held in place, install the remaining clamps in the same fashion and snug them in place.
9. If track does not tighten to the piling after tightening the 5" compression bolt, place one of the 2 $\frac{1}{2}$ " x 4" x $\frac{3}{8}$ " white spacers between the track and the piling as close to the clamp as possible. This will make up for the irregularity of the pilings.
 - a. On pilings with severe differences in size you may need to add two spacers.
10. When track location is confirmed as correct and clamps are firmly tightened, install the shear lag bolt through the $\frac{3}{8}$ " hole in clamp and into piling. This will ensure that there will be no twisting of the clamps on piling.
11. Remove protective coating from the band.
12. Now follow the instructions for assembling the SlideMoor Slide and then place it on the track by sliding it on from the top of the track.
13. Be sure to install the top track stop bolt when done with the rest of the installation.